



HOPE **XD DRIVER**

When fitting a Sram cassette to an XD driver body, you must first remove the silver drive side spacer before fitting the cassette. This allows the spline tool to fully engage.

Pull off only the spacer with a suitable grip, then fit the cassette to the manufacturers specified torque. Once the cassette is fully torqued, push the spacer back onto the hub.

The same procedure applies for the removal of the cassette.